

Mounting instructions PCD7.D4xxx

The displays are mounted with clamps. These instructions shall be followed to avoid breaking of the clamp or breaking of the display and ensure proper operation of the device.



Warning
IMPORTANT MOUNTING INSTRUCTION
Do not use an electric screw driver



Use instead a 2.5 mm Allen key (Hex wrench) to mount the clamps. For all displays a torque of 20 cNm is needed to compress the sealing gasket.

Warning the maximum torque shall not exceed 30 cNm to avoid breaking of the clamp.



- 1 Place the display in the emplacement
- 2 Insert the clamps in the openings
- 3 Screw all clamps with the required torque

Display size	Clamps QTY required
5"/5.7"	4
7"/10"	6
12"	8

The clamps shall be disposed for each panel as below:

