



- Ⓕ Relais de contrôle de phase
- ⒼⒷ Phase control relay
- Ⓓ Phasenüberwachungsrelais
- Ⓘ Relè di controllo delle fasi
- ⒫ Relé de controlo de fases
- Ⓔ Relé de control de fases

Notice d'instructions  
 User instructions  
 Bedienungsanleitung  
 Istruzioni d'impiego  
 Instruções de instalação  
 Hoja de instrucciones

## KFE 300

P	≤ 4 VA
Un	400 V~ 50...60Hz
T °C	-20 ... +55 °C
Ik	3
IP	20
	8 A / AC1 / 250V~

